

ENVIRO-TOP™

IMPORTANT! Read these instructions carefully several days prior to starting your work. Seek answers to any questions you may have before you begin. DUR-A-FLEX, Inc. maintains a Technical Staff that will be glad to answer your questions and give you advice pertaining to your particular installation.

ENVIRO-TOP™ is applied by “brush and roller”.

When recommended spread rates are followed, a single coat of ENVIRO-TOP™ can yield between 1.5 – 3 mils DFT at 350 to 400 square feet per gallon kit. ENVIRO-TOP™ comes in a high gloss or satin finish offering UV blocking capabilities. ENVIRO-TOP™ is recommended for use on DUR-A-WALL systems in areas where low odor and minimal downtime is necessary.

MIXING AREA

Select a convenient mix area and protect the surface from spillage by covering with a layer of cardboard and/or sheet of plastic. Be generous with the amount of space you allocate for this function. The more comfortably your mixer works, the less likely you are to have a “mix error”. Make ready all necessary tools, mix and measure containers, etc. **DO NOT MIX ANY URETHANE UNTIL READY FOR USE.** Apply masking tape wherever coating is intended to stop. To obtain neat, straight, chip resistant edges at termination points and/or drains, a “keyed edge” must be installed.

1) MIXING

- A. Premix Resin component.
- B. SATIN FINISH: 3 Component Satin Kit
 - i) Thoroughly shake ENVIRO-TOP™ LG Additive to uniformly disperse the additive.
 - ii) Add ENVIRO-TOP™ LG Additive to ENVIRO-TOP™ Resin.
 - iii) Shake moderately for 2 minutes
 - iv) Add 13 oz ENVIRO-TOP™ Hardener and shake moderately for 1 minute.
 - v) Allow 5 minutes induction prior to use.

- C. GLOSS FINISH: 2 Component Kit Add ENVIRO-TOP™ Hardener to ENVIRO-TOP™ Resin and shake for 1 minute. Allow 5 minutes induction time.

Important: For maximum benefits, allow blended waterborne urethane to stand (induct) for a minimum of 5 minutes before application. The induction period is critical because it allows the foam to stabilize.

2) DIP and ROLL METHOD

- D. After induction gently remix material, pour into a paint tray, and apply using a dip and roll method.
- E. Apply material using a high quality non-shed 3/8” nap roller at 350-400 sq.ft./gallon, 3-5 mils wet (1.5-3 mils DFT). Roll material on to wall at proper spread rate and back roll the wall from top to bottom.
- F. **DO NOT** apply if Relative Humidity is 90% or higher.
- G. When applied, ENVIRO-TOP™ looks milky/translucent white, but it will cure clear.
- H. Clean up with soap and warm water.

CAUTION

Follow the Hazardous Materials Identification System labeling guide for proper personal protective equipment to use when handling this product. Use only as directed. KEEP OUT OF REACH OF CHILDREN.

Before using any DUR-A-FLEX, Inc. Product, be sure the Material Safety Data Sheet is read and understood.