

## **NO-SAG #1**

### **DESCRIPTION**

NO-SAG #1 is a dry powder designed to thicken ELAST-O-COAT while allowing it to remain flexible. The thickened epoxy is used to fill control joints where movement is expected. It is typically applied with a trowel or caulking gun.

### **TYPICAL USES**

NO-SAG #1 is required when applying ELAST-O-COAT with fiberglass tape over seams on floor applications over plywood. NO-SAG #1 can also be used to prevent ELAST-O-COAT from seeping into control joints.

### **MIX FOR CRACK FILLING (moving)**

1 quart of Hardener (A)

½ gallon of Resin (B)

1 gallon NO-SAG #1

For larger areas, double the above recommendations.

### **APPLICATION METHOD**

The best method of adding this product to epoxy is to add the epoxy resin to the hardener, stir until blended well, then add the NO-SAG #1 to the mixing liquids. Adjust amount to increase viscosity to the consistency desired. One gallon of NO-SAG #1 weighs approximately 1 lb.

### **LIMITATIONS**

Minimum temperature of 55°F is required during curing period. This product is not designed to be used with DUR-A-GLAZE #4.

### **PACKAGING**

NO-SAG #1 is packaged in 25 lb bags.

### **CAUTION**

As with all fine powders and dust, avoid inhalation of particles. Wear gloves because the fine powder will absorb skin moisture. Wash hands after contact. **Follow the Hazardous Materials Identification System labeling guide for proper personal protective equipment to use when handling this product. Use only as directed. KEEP OUT OF REACH OF CHILDREN.**

***Before using any DUR-A-FLEX, Inc. product, be sure the Material Safety Data Sheet is read and understood.***