



$D = W/2$   
 D = DEPTH OF BACKER ROD  
 W = WIDTH OF EXPANSION JOINT



**DUR-A-FLEX**  
 INNOVATION FROM THE FLOOR UP

[www.dur-a-flex.com](http://www.dur-a-flex.com)  
**860-528-9838**

TITLE

**POLY-CRETE SLB**

**EXPANSION JOINT DETAIL**

DATE

10 / 11

SCALE

AS NOTED

DWG NO.

**PCSL-3**

PROJECT