



$D = W/2$   
 D = DEPTH OF BACKER ROD  
 W = WIDTH OF JOINT



**DUR-A-FLEX®**  
 INNOVATION FROM THE FLOOR UP

[www.dur-a-flex.com](http://www.dur-a-flex.com)

**860-528-9838**

TITLE

**HYBRI-FLEX**

PIPE / DUCT BREACHE DETAIL

DATE

10 / 11

SCALE

AS NOTED

DWG NO.

HF-15

PROJECT