



$D = W / 2$
 D = DEPTH OF BACKER ROD
 W = WIDTH OF EXPANSION JOINT



DUR-A-FLEX
 INNOVATION FROM THE FLOOR UP

www.dur-a-flex.com
860-528-9838

TITLE

ACCELERA C, Q, B, HC, HQ, HB
 EXPANSION JOINT DETAIL

DATE

6 / 15

SCALE

NTS

DWG NO.

AF-3

PROJECT