



$D = W / 2$
 D = DEPTH OF BACKER ROD
 W = WIDTH OF EXPANSION JOINT



DUR-A-FLEX
 INNOVATION FROM THE FLOOR UP

www.dur-a-flex.com
860-528-9838

TITLE

MMA FLOORING

EXPANSION JOINT DETAIL

DATE

10 / 11

SCALE

AS NOTED

DWG NO.

MMA-3

PROJECT