



$D = W / 2$
 D = DEPTH OF BACKER ROD
 W = WIDTH OF JOINT



DUR-A-FLEX
 INNOVATION FROM THE FLOOR UP

www.dur-a-flex.com
860-528-9838

TITLE **POLY-CRETE MD, MDB, MDC, MDQ**
 ISOLATION JOINT DETAIL WITH COVE

DATE
 10 / 11

SCALE
 AS NOTED

DWG NO.
PCMD-9

PROJECT