



$D = W/2$
 D = DEPTH OF BACKER ROD
 W = WIDTH OF JOINT



DUR-A-FLEX®
 INNOVATION FROM THE FLOOR UP

www.dur-a-flex.com

860-528-9838

TITLE

POLY-CRETE SLB

PIPE / DUCT BREACHE DETAIL

DATE

10 / 11

SCALE

AS NOTED

DWG NO.

PCSL-14

PROJECT