



$D = W / 2$   
 D = DEPTH OF BACKER ROD  
 W = WIDTH OF JOINT



**DUR-A-FLEX**  
 INNOVATION FROM THE FLOOR UP

[www.dur-a-flex.com](http://www.dur-a-flex.com)  
**860-528-9838**

TITLE		<b>POLY-CRETE SLB</b>	
		ISOLATION JOINT DETAIL WITH COVE	
DATE	10 / 11	SCALE	AS NOTED
DWG NO.	PCSL-7	PROJECT	