

HYBRI-FLEX MC

IMPORTANT! Read these instructions carefully several days prior to starting your work. Seek answers to any questions you may have before you begin. DUR-A-FLEX, Inc. maintains a Technical Staff that will be glad to answer your questions and give you advice pertaining to your particular installation.

SYSTEM OVERVIEW

HYBRI-FLEX MC is a 100% solids, decorative chip system composed of a 1/8" POLY-CRETE SL body coat with a decorative chip broadcast. It uses a 16 mil CRYL-A-GLAZE G-201 broadcast coat, and two 16 mil CRYL-A-TOP T-301/T303 topcoats yielding a total nominal system thickness of 3/16".

SURFACE PREPARATION

Surface should be profiled, clean, dry, oil free and sound. Shot Blasting is the preferred preparation method. Please refer to the master Surface Preparation Guide on our website for more information. Never feather edge HYBRI-FLEX MC, always terminate in a keyway groove at doorways, drains and exposed edges.

MOISTURE CONCERNS

Please refer to the Floor Evaluation Guidelines in the Contractor's Center of our website for a step-by-step process to determine the condition of the concrete.

MIXING AREA

Select a convenient mix area and protect the surface from spillage by covering with a sheet of plastic and a layer of cardboard. Be generous with the amount of space allocated for this function. The more comfortably your mixer works, the less likely you are to have a "mix error". Please refer to the Mix Station video on our website for more information.

STORAGE CONDITIONS

POLY-CRETE SL must be stored dry. Exposure of the aggregate to moisture for an extended period will cause lumps. Do not allow resins to freeze. The shelf life is 6 months from the ship date in the original unopened container. Products must be stored in temperatures no less than 60°F and no greater than 85°F.

JOINT GUIDELINES

Refer to the Joint Guidelines for complete details on our website.

APPLICATION METHOD

Proper planning is essential for satisfactory appearance of the finished floor. Lay out installation in sections to allow full width to be finished in 20 minutes (@70°F) or less to assure absence of placement lines.

NOTE: For each application of material and before mixing, mark your batches to ensure you achieve your spread rate targets. This is best accomplished by dividing your target spread rate by the width of the area being coated (or your planned wet edge). Example: If your spread rate is 100 square feet and your area is 20 feet wide you would make a mark every 5 feet (100 divided by 20 = 5).

PRIMER

In most applications HYBRI-FLEX MC does not require a primer. However, very porous substrates should be primed first with POLY-CRETE TF PLUS.

- A. POLY-CRETE TF PLUS is supplied in pre-measured units consisting of one pail of resin, one container of hardener and one bag of aggregate (powder). Pour the POLY-CRETE TF PLUS resin into a 2-gallon pail; scrape bottom and sides with a mix stick to assure that all material is transferred to the mix bucket. Use the Poly-Crete pail to scrape the mix stick, never scrape mix stick on the side of the mix pail. Measure out 0.25 fluid ounces of POLY-CRETE HF ACCELERATOR, add to the mix bucket and mix the resin and accelerator for one minute. Pour the entire POLY-CRETE TF PLUS hardener into the center of the mix bucket. Using a 1/2" 850 RPM drill with a 4" dispersion blade, mix the resin and hardener for 30 seconds. Slowly add the POLY-CRETE TF PLUS aggregate to the resin and hardener and mix at 850 RPM for 1 minute. **PRODUCT MUST BE MIXED WITH A 4" DISPERSION BLADE AND A 1/2" VARIABLE SPEED 850 RPM DRILL. DO NOT ADD HARDENER TO RESIN UNTIL BATCH IS READY FOR MIXING. FAILURE TO ADD ALL POLY-CRETE TF PLUS POWDER WILL RESULT IN IMPROPER CURE OF MATERIAL.**
- B. Pour the entire batch onto the floor in a 4 to 6" ribbon. Use a 1/8" V-Notch squeegee to spread the material at 90 square feet per kit and back/cross roll using a 18" wide,

3/8" nap roller to ensure there are no puddles. Allow to cure for 6 hours at 70°F.

BASECOAT

- A. POLY-CRETE SL is supplied in pre-measured units consisting of one pail of resin, one container of hardener and one bag of aggregate (powder). Pour the POLY-CRETE SL resin into a metal 5-gallon pail; scrape bottom and sides with a mix stick to assure that all material is transferred to the mix bucket. Use the Poly-Crete pail to scrape the mix stick, never scrape mix stick on the side of the mix pail. Pour all of the POLY-CRETE SL hardener into the center of the mix bucket. (If using POLY-CRETE NATURAL SL with pigment add the pigment to the resin and hardener.) Next, using a ½" 850 RPM drill with a 4" dispersion blade, mix the resin and hardener for 30 seconds. Slowly add the POLY-CRETE SL aggregate to the resin and hardener and mix at 850 RPM for 1 minute. **PRODUCT MUST BE MIXED WITH A 4" DISPERSION BLADE AND A ½" VARIABLE SPEED 850 RPM DRILL. DO NOT ADD HARDENER TO RESIN UNTIL BATCH IS READY FOR MIXING. FAILURE TO ADD ALL POLY-CRETE SL AGGREGATE WILL RESULT IN IMPROPER CURE OF MATERIAL.**
- B. Pour the entire batch onto the floor and spread with a ½ V notched squeegee. Each kit of POLY-CRETE SL will yield 55 Sq. Ft. per kit. Check squeegee every 1,000 sq. ft. for wear. Have a new squeegee ready to avoid interruption in the process.
- C. Use a flat trowel to cut in edges, drains and around equipment. For continuity of finish and to ensure that new batches of material are blended together without transition lines, use even pressure and trowel at a low angle using a sweeping motion. To remove squeegee lines and help the material level, immediately Loop Roll the material after it has been placed. The material should be rolled straight forward and back picking up the roller with each pass; this will avoid leaving divots in floor. After the squeegee lines have been removed the floor should be cross rolled side to side along the entire wet edge. The final cross roll should be completed within 12 minutes of mixing the product at 70°F.
- D. While wearing spiked shoes broadcast the chips up into the air and let them fall into the floor. Make sure the broadcast is dispersed evenly over the entire floor area at a rate of 0.1lbs per square foot. Wait 15 minutes from start of mix before beginning the broadcast and complete broadcasting within 30 minutes from start of mix. Do not roll or walk back onto areas that have been broadcast. Allow POLY-CRETE SL to cure for a minimum of 8 hours at 70°F.
- E. Use a stiff bristle broom to sweep off excess chip. Use a vacuum to remove chips around the edges and corners that are not accessible with a broom.

VENTILATION

Prior to any application, proper "negative pressure" ventilation must be established. Please refer to the CRYL-A-FLEX Ventilation Guidelines on our website.

SECOND BROADCAST

- A. Due to the short working time of Cryl-A-Flex products mix only what can be placed in 10 minutes. Typical batch size is 1 gallon. The amount of CRYL-A-CURE activator powder used is based upon substrate temperature. Be sure to use an infrared thermometer to measure substrate temperature. Refer to the CRYL-A-CURE MIX CHART for appropriate amount based on ounces per gallon.
- B. Measure out 1 gallon of CRYL-A-GLAZE G-201 resin. Then measure out appropriate amount of CRYL-A-CURE based on substrate temperature. First pour the CRYL-A-GLAZE G-201 into a 2-gallon mix pail, then add appropriate amount of CRYL-A-CURE.
- C. Using a ½" 850 RPM drill with a Jiffler blade, mix the CRYL-A-GLAZE G-201 and CRYL-A-CURE for 30 seconds. ***DO NOT ADD CRYL-A-CURE TO CRYL-A-GLAZE UNTIL BATCH IS READY FOR MIXING***
- D. Pour entire batch in a 4" to 6" ribbon along the starting area. Use a 3" chip brush to cut in along edges, doorways, and drains.
- E. Using a solvent resistant, 18" 3/8" nap roller, pull the material from side to side overlapping passes every 6". Be careful not to leave any puddles. CRYL-A-GLAZE G-201 is applied at 80 Sq. Ft. per gallon over decorative chip.
- F. Using a solvent resistant, 18" 3/8" nap roller, cross roll the material side to side overlapping the previous pass with half the roller width.
- G. Broadcast chip up into the air and let it fall onto the floor. Make sure the broadcast is dispersed evenly over the entire floor area at a rate of 0.1lbs per square foot. DO NOT OVER BROADCAST. THIS WILL INHIBIT THE CURE OF CRYL-A-GLAZE G-201. Do not roll or walk back into areas that have been broadcast. CRYL-A-GLAZE will cure completely in 40 to 60 min.
- H. Use a stiff bristle broom to sweep off excess chips. Use a vacuum to remove loose chips from around the edges and corners that are not accessible with a broom.

TOP COAT INSTRUCTIONS

NOTE: Use Cryl-A-Top T301 for interior applications, and Cryl-A-Top T303 for exterior applications.

- A. Due to the short working time of Cryl-A-Flex products mix only what can be placed in 10 minutes. Typical batch size is 1-gallon. The amount of CRYL-A-CURE activator powder used is based on substrate temperature. Be sure to use an infrared thermometer to measure substrate temperature. Refer to the CRYL-A-CURE MIX CHART for appropriate amount based on ounces per gallon.

- B. Measure out 1 gallon of CRYL-A-TOP resin. Then measure out appropriate amount of CRYL-A-CURE based on substrate temperature. First pour the CRYL-A-TOP into a 2 gallon mix pail and then add appropriate amount of CRYL-A-CURE.
- C. Using a ½” 850 RPM drill with a Jiffler blade, mix the CRYL-A-TOP and CRYL-A-CURE for 30 seconds. ***DO NOT ADD CRYL-A-CURE TO CRYL-A-TOP UNTIL BATCH IS READY FOR MIXING***
- D. Pour entire batch in a 4 to 6” ribbon along the starting area. Use a 3” chip brush to cut in along edges, doorways, and drains.
- E. Using a solvent resistant, 18” 3/8” nap roller, pull the material from side to side overlapping passes every 6”. Be careful not to leave any puddles. CRYL-A-TOP is applied at 80 Sq. Ft. per gal over decorative chip.
- F. Using a solvent resistant, 18” 3/8” nap roller, cross roll the material side to side overlapping the previous pass with half the roller width.
- G. CRYL-A-TOP will cure completely in 40 to 60 minutes. For second topcoat repeat instructions A-F. The coverage rate will increase to 100-110 Sq. Ft. per gallon on the second top coat.

NOTE: This product is best suited for application in temperatures between 60°F and 85°F. CRYL-A-FLEX resins are flammable liquids in their uncured state. Smoking, open flames or sparks should not be permitted during the handling of the product.

IMPORTANT!

Before using DUR-A-FLEX products, read and understand its accompanying Safety Data Sheet.

STANDARD TERMS AND CONDITIONS OF SALE, INCLUDING STANDARD WARRANTY APPLY - VISIT **DUR-A-FLEX.COM** FOR THE LATEST VERSION

CAUTION! As with all chemical products, individuals may have different reactions to exposure to specific products. This is dependent upon many factors, including the individual's personal characteristics, the size of the installation, the ventilation available, the intensity of the exposure or the length of the exposure. Individuals may experience discomfort during the installation process of one product, but not another.

In some cases this is experienced as a skin irritation and in others it is experienced as an inhalant irritation. Typically, it disappears once the exposure is eliminated. In some cases people can become “sensitized” to a product and experience the discomfort every time there is exposure without Personal Protective Equipment (“PPE”).

To protect yourself from various exposures or discomfort during the mixing and application of our products, we recommend covering exposed skin including, using gloves, long sleeves, safety glasses and a respirator such as the 3M 8577 P95 Universal Disposable Carbon Respirator or a cartridge respirator.

Use only as directed. KEEP OUT OF REACH OF CHILDREN.

Do not reseal moisture-contaminated hardener. This will result in carbon dioxide generation or possible violent rupture of container.