



$D = W / 2$
 D = DEPTH OF BACKER ROD
 W = WIDTH OF JOINT



DUR-A-FLEX
 INNOVATION FROM THE FLOOR UP

www.dur-a-flex.com
860-528-9838

TITLE

MMA FLOORING

ISOLATION JOINT DETAIL
WALL FLOOR JUNCTION

DATE

10 / 11

SCALE

AS NOTED

DWG NO.

MMA-6

PROJECT