



D = W / 2
 D = DEPTH OF BACKER ROD
 W = WIDTH OF JOINT



DUR-A-FLEX
 INNOVATION FROM THE FLOOR UP

www.dur-a-flex.com
860-528-9838

TITLE		POLY-CRETE SLB	
		ISOLATION JOINT DETAIL	
DATE	10 / 11	SCALE	AS NOTED
DWG NO.	PCSL-6	PROJECT	