



# DUR-A-CRETE 4TM “EASY MIXER” PATCHING KIT



## 1) Combine Hardener with Resin.

Pour contents of can marked HARDENER into the can marked RESIN and stir vigorously for 1-1/2 minutes.

## 2) Mix with sand.

Without delay pour blended epoxy into plastic bag to mix with sand. Seal top with plastic tie. Shake vigorously and then knead until sand is saturated thoroughly with epoxy mixture.



## 3) Trowel smooth.

Pour prepared grout on area to be filled and levelled. Spread loosely to desired thickness, then tamp to compact and smooth with trowel.

If less than full amount is to be used, combine by volume 1 part HARDENER with 2 parts RESIN.

Resin-rich mixture normally does not require a prime coat. Minimal surface preparation is needed however is recommended.

Accurate measuring and thorough mixing is mandatory.

