

ACELERA INSTALLATION CHECKLIST

- 1/2" 750 RPM high torque drill
- 5" & 3" jiffler blades
- Extension cords
- Mix & measure kits
- 5 gallon pails: metal & plastic
- 2 gallon pails
- 1 gallon pails
- Rags
- Dur-A-Solve (or similar xylene based solvent)
- Cardboard and plastic for mix station
- Paint sticks
- Utility Knife
- 5 in 1 Tool
- Blue tape
- Duct tape
- Garbage bags
- Floor machine / buffer/ sander
- Sanding discs: 20 & 36 grit
- Sanding screens: 80 & 120 grit
- Palm sander
- Latex gloves (or similar)
- 3M 8511, N95 Particulate Respirator
- Hardhat
- Safety glasses
- Knee pads
- Spike shoes
- Dust masks
- LED / Halogen lighting
- 1/8" Cove strip
- Vacuum
- Stiff bristle brooms
- Squeegees: flat & notched
- Gauge rake for self-level applications
- 18" roller covers, frames, pans
- 9" roller covers, frames, pans
- 3" chip brushes
- Adjustable pin rake (RXC)
- Metal Pin Roller (RXC)
- Margin trowels
- Flat finish trowels: 3" x 12" & 4" x 14"
- Cove trowels: 4" & 6" (have 2 of each)
- Rub stones (Marshalltown)
- Drum valves 2" & 3/4"
- Drum wrench
- Drum carts
- Leaf blowers (electric or battery powered)

NOTE: Read and understand the Application Instructions and Product Data Sheets before working with any Dur-A-Flex products. Proper PPE is the responsibility of the individual using the products. To protect yourself from various exposures or discomfort during the mixing and application of our products, we recommend covering exposed skin including, using gloves, long sleeves, safety glasses and a respirator such as the 3M 8577 P95 Universal Disposable Carbon Respirator or a cartridge respirator.