

POLY-CRETE® SL INSTALLATION CHECKLIST

This checklist is a comprehensive list of materials and tools needed for installing either Poly-Crete SL or a Poly-Crete SLB flooring system.

- 1/2" 850 RPM High speed drill
- 5 gallon metal pails
- 4" Dispersion blade
- Extension cords
- Rags
- Dur-A-Solve (or similar xylene based solvent)
- Cardboard & plastic for mix station
- Paint sticks
- Utility Knife
- 5 in 1 tool
- Duct tape
- Blue tape
- Garbage bags
- Hard hat
- Safety glasses
- Knee pads
- Spike shoes
- Latex gloves (or similar)
- Dust masks
- 1/2" V-Notched squeegee (1 per 1000 SF)
- 12" Flat squeegee
- 18" Loop roller
- 18" Roller frames
- 18"w 3/8" Nap roller covers
- Vacuum
- Stiff bristle brooms
- 3" Chip brushes
- 4 x 14" Finish trowels
- 2 gallon broadcast buckets

NOTE: Read and understand the Application Instructions and Product Data Sheets before working with any Dur-A-Flex products. Proper PPE is the responsibility of the individual using the products. To protect yourself from various exposures or discomfort during the mixing and application of our products, we recommend covering exposed skin including, using gloves, long sleeves, safety glasses and a respirator such as the 3M 8577 P95 Universal Disposable Carbon Respirator or a cartridge respirator.