

DUR-A-GLAZE#4 ESD PRIMER / DUR-A-GARD ESD

IMPORTANT! Read these instructions carefully several days prior to starting your work. Seek answers to any questions you may have before you begin. DUR-A-FLEX, Inc. maintains a Technical Staff that will be glad to answer your questions and give you advice pertaining to your particular installation.

INSTALLATION OVERVIEW

The general steps required to install this system are:

1. Prepare the slab-shot blast, patch, honor joints
2. Prime with DUR-A-GLAZE #4 ESD PRIMER
3. Install copper foil tape
4. Install DUR-A-GARD ESD topcoat
5. Test resistivity at 24 hrs.

SURFACE PREPARATION

Surface must be sound, dry and perfectly clean, free of all oil, grease, detergent film, sealers and/or curing compounds. A surface profile of 10 to 15 mils is appropriate for most applications. All paint should be removed unless it is a properly applied, totally de-glossed, high quality epoxy. Upper level rooms, like mechanical rooms, bathrooms, or wet process areas that have space below should receive ELAST-O-COAT seamless fluid applied membrane. Please refer to the DUR-A-FLEX Surface Preparation Guide on our website for detailed instructions.

JOINT GUIDELINES

Refer to the Joint Guidelines for complete details on our website.

MIXING AREA

Select a convenient mix area and protect the surface from spillage by covering with a layer of cardboard and/or sheet of plastic. Be generous with the amount of space you allocate for this function. The more comfortably your mixer works, the less likely you are to have a “mix error”. Make ready all necessary tools, mix and measure containers, etc. **DO NOT MIX ANY EPOXY UNTIL READY FOR IMMEDIATE USE.** Once hardener and resin are combined, it must be used without delay, working time is dependent on size of batch and the temperature of the floor and product. Apply masking tape wherever coating is intended to stop. To obtain neat, straight, chip resistant edges at termination points and/or drains, a “keyed edge” must be installed.

PRE-PATCH

Do pre-patch badly eroded, spalled or cracked areas with DUR-A-CRETE. Use ELAST-O-COAT for moving joints, and DUR-A-GLAZE #4 mixed with NO-SAG #2 or FLINTSHOT for non-moving joints. **BE SURE TO LEAVE AS LITTLE EXCESS AS POSSIBLE AS IT WILL BE HIGHLIGHTED IN SUCCESSIVE STEPS.**

PRIMING WITH DUR-A-GLAZE #4 ESD PRIMER

All surfaces must be primed with DUR-A-GLAZE #4 ESD PRIMER as soon as the surface has been prepared. Due to the porosity of the concrete, the possibility of out gassing may occur after shot blasting, if this occurs, a second primer coat is needed.

SIMONIZ 969 Detergent/Degreaser is recommended to clean oily concrete slabs.

Be sure to apply primer **before** oil has a chance to “wick” up to the top of the slab and migrate across the surface.

1. Pre-mix hardener and resin components separately before combining.
2. DUR-A-GLAZE #4 ESD PRIMER is mixed 1 part Hardener to 2 parts Resin mix ratio. Measure out 1/2 gallon of DUR-A-GLAZE #4 ESD PRIMER hardener and 1 gallon of DUR-A-GLAZE #4 ESD PRIMER resin. When combining, be sure to add the hardener first. Add the resin and scrape out the container. Be careful to pour both hardener and resin into the center of the mixing pail. Mix the blended epoxy with a slow speed power drill with a Jiffler mixing blade for 3 minutes. Always scrape the sides and bottom of the mixing bucket to assure thorough blending.
3. Pour a 4 to 6 inch “ribbon” of blended epoxy onto the floor (typically along the far wall or a joint). DUR-A-GLAZE #4 ESD PRIMER is typically applied at 200 Sq Ft per gallon to yield 8 mils DFT per coat with a 1/8” notched squeegee. Back roll with a quality non-shed 3/8” nap roller. Cross roll entire area as you go, while wearing spiked shoes. Be sure to remove any impurities as you see them. It is much harder to cut or grind them out after the product has cured. Allow to cure.

COPPER FOIL TAPE INSTALLATION

Install Copper foil tape conductive adhesive to ground (such as metal support columns). Copper foil tape is available from McMaster-Carr Company (www.mcmaster.com). Dur-A-Flex, Inc. recommends using the 1/2" tape with conductive adhesive part number 76555A642. Copper foil tape should be installed at one point per 1,000 square feet minimum.

QUALITY CONTROL

The color of DUR-A-GARD ESD resin may vary slightly from batch to batch. It is recommended that the lot number on the side of the resin pail be checked, if lot numbers are different, segregate and apply each lot continguously to minimize slight color variations on the floor.

TOP COAT WITH DUR-A-GARD ESD

After priming with DUR-A-GLAZE #4 ESD PRIMER and installing Copper foil tape to grounds, Topcoat with DUR-A-GARD ESD.

1. Pre-mix hardener and resin components separately before combining.
2. DUR-A-GARD ESD is mixed in a 1part Hardener to 3 parts Resin mix ratio. Measure out 1/2 gallon of DUR-A-GARD ESD hardener and 1 1/2 gallons of DUR-A-GARD ESD resin. When combining, be sure to add the hardener first. Add the resin and scrape out the container. Be careful to pour both hardener and resin into the center of the mixing pail. Mix the blended epoxy with a slow speed power drill with a Jiffler mixing blade for 3 minutes. Always scrape the sides and bottom of the mixing bucket to assure thorough blending.
3. Pour a 4 to 6 inch "ribbon" of blended epoxy onto the floor (typically along the far wall or a joint). DUR-A-GARD ESD is typically applied at 100 Sq Ft per gallon to yield 16 mils DFT per coat with a 3/16" notched squeegee and then back rolled with a quality non-shed 3/8" nap roller. Cross roll entire area as you go, while wearing spiked shoes. Be sure to remove any impurities as you see them. It is much harder to cut or grind them out after the product has cured. Allow to cure.
4. Successive coats can be applied to achieve the desired thickness.

THICKNESS OF COATING APPLIED (1000 MILS = 1 INCH)		COVERAGE PER US GALLON 100% SOLIDS SYSTEM	
	20 MILS	80.0	SQ FT/GAL
1/64 IN. =	16 MILS	102.0	SQ FT/GAL
	10 MILS	160.0	SQ FT/GAL
	8 MILS	200.0	SQ FT/GAL

TESTING RESISTIVITY

Once DUR-A-GARD ESD has cured for 24 hours at 70°F, resistance readings should be taken to ensure the floor is reading properly. DUR-A-FLEX, Inc. recommends using the OHM-STAT RT-1000 Megohmmeter from Static Solutions. Floor readings should be tested at 100V and read between 10⁶-10⁹ Ω/Square.

IMPORTANT!

Increasing room temperature to accelerate cure is not recommended, a slight reduction (3°-5°F) from reasonable room temperature may help reduce out gassing. DUR-A-GARD ESD is a high gloss finish and special care should be given to avoid surface contamination. USE SIGNS AND BARRIERS to keep traffic out of the area. Do not allow any water on coated surface for 24-48 hours. Chemical spillage must be prevented for approximately 5 days. **NOTE:** Use DUR-A-SOLVE or a lacquer thinner for clean up. This product is suitable for applications between 60° and 85° F concrete slab temperature.

DO NOT THIN DUR-A-GLAZE #4 ESD PRIMER OR DUR-A-GARD ESD WITH SOLVENT.

CAUTION

Follow the Hazardous Materials Identification System labeling guide for proper personal protective equipment to use when handling this product. Use only as directed. **KEEP OUT OF REACH OF CHILDREN.**

Before using any DUR-A-FLEX, Inc. Product, be sure the Material Safety Data Sheet is read and understood.