

HYBRI-FLEX® EC

IMPORTANT! Read these instructions carefully several days prior to starting your work. Seek answers to any questions you may have before you begin. DUR-A-FLEX, Inc. maintains a Technical Staff that will be glad to answer your questions and give you advice pertaining to your particular installation.

SYSTEM OVERVIEW

HYBRI-FLEX EC is a decorative chip system composed of a 1/8" POLY-CRETE SL body coat with a decorative chip broadcast. It uses a DUR-A-GLAZE #4 broadcast coat, a DUR-A-GLAZE #4 grout coat, and an ARMOR TOP topcoat yielding a total nominal system thickness of 3/16".

SURFACE PREPARATION

Surface should be profiled, clean, dry, oil free and sound. Shot Blasting is the preferred preparation method. Please refer to the master Surface Preparation Guide on our website for more information. Never feather edge HYBRI-FLEX EC, always terminate in a keyway groove at doorways, drains and exposed edges. No epoxy coatings should be applied unless surface temperature is a minimum of 5 degrees F above dew point. See Dew Point Calculation Chart on our website for detailed instructions.

MOISTURE CONCERNS

Please refer to the Floor Evaluation Guidelines in the Contractor's Center of our website for a step-by-step process to determine the condition of the concrete.

MIXING AREA

Select a convenient mix area and protect the surface from spillage by covering with a sheet of plastic and a layer of cardboard. Be generous with the amount of space allocated for this function. The more comfortably your mixer works, the less likely you are to have a "mix error". Please refer to our Mix Station video on our website for more information.

STORAGE CONDITIONS

POLY-CRETE SL must be stored dry. Exposure of the aggregate to moisture for an extended period will cause lumps. Do not allow resins to freeze. The shelf life is 6 months from the ship date in the original unopened container. Products must be stored in temperatures no less than 60°F and no greater than 85°F.

JOINT GUIDELINES

Refer to the Joint Guidelines for complete details on our website.

APPLICATION METHOD

Proper planning is essential for satisfactory appearance of the finished floor. Lay out installation in sections to allow full width to be finished in 20 minutes (@70°F) or less to assure absence of placement lines.

NOTE: For each application of material and before mixing, mark your batches to ensure you achieve your spread rate targets. This is best accomplished by dividing your target spread rate by the width of the area being coated (or your planned wet edge). Example: If your spread rate is 100 square feet and your area is 20 feet wide you would make a mark every 5 feet (100 divided by 20 = 5).

PRIMER

In most applications HYBRI-FLEX EC does not require a primer. However, very porous substrates should be primed first with POLY-CRETE TF.

- A. POLY-CRETE TF is supplied in pre-measured units consisting of one pail of resin, one container of hardener and one bag of aggregate (powder).
- B. Pour resin into the 2 gallon mix container.
- C. Scrape the sides of the resin container with a paint stick making sure no amount of residue remains.
- D. Wipe excessive material from paint stick on rim of resin bucket – DO NOT wipe excessive material from stick on the rim of the mixing bucket.
- E. Add hardener, same as steps C and D, scrape the sides of the bucket.
- F. Use a High Speed Drill with a 5-inch Jiffler blade.
- G. Thoroughly mix resin and hardener for 30 seconds.
- H. To avoid any possible clumping, add POLY-CRETE TF PLUS Aggregate while mixing the resin and hardener.
- I. Thoroughly mix resin, hardener and aggregate for 60 seconds.
- J. Make sure there are no clumps in the mixed materials.
- K. Pour the entire mixed material onto the floor in 4-inch ribbons.
- L. Scrape out all mixed material with paint stick and do not leave any residue in mix bucket.
- M. Spread with a 1/8-inch notched squeegee east to west and apply the material uniformly at 90 SF @ 8 mils

thickness. When moving east to west move squeegee in a continuous semi-circular motion.

- N. Wet out rollers in a puddle prior to using. Back roll north to south to level the material.
- O. Cross roll east to west to eliminate any roller lines overlapping 4-inches in between each cross roll.

BASECOAT

- A. POLY-CRETE SL is supplied in pre-measured units consisting of one pail of resin, one container of hardener and one bag of aggregate (powder). Pour the POLY-CRETE SL resin into a metal 5-gallon pail; scrape bottom and sides with a mix stick to assure that all material is transferred to the mix bucket. Use the Poly-Crete pail to scrape the mix stick, and never scrape the mix stick on the side of the mix pail. Pour the entire POLY-CRETE SL hardener into the center of the mix bucket. (If using POLY-CRETE NATURAL SL with pigment add the pigment to the resin and hardener.) Next, using a ½" 850 RPM drill with a 4" dispersion blade, mix the resin and hardener for 30 seconds. Slowly add the POLY-CRETE SL aggregate to the resin and hardener and mix at 850 RPM for 1 minute.
PRODUCT MUST BE MIXED WITH A 4" DISPERSION BLADE AND A ½" VARIABLE SPEED 850 RPM DRILL. *DO NOT ADD HARDENER TO RESIN UNTIL BATCH IS READY FOR MIXING*. *FAILURE TO ADD ALL POLY-CRETE SL AGGREGATE WILL RESULT IN IMPROPER CURE OF MATERIAL*
- B. Pour the entire batch onto the floor and spread with a ½ V notched squeegee. Each kit of POLY-CRETE SL will yield 55 Sq. Ft. per kit. Check squeegee every 1000 sq feet for wear. Have new squeegee ready to avoid interruption in the process.
- C. Use a flat trowel to cut in edges, drains and around equipment. For continuity of finish and to ensure that new batches of material are blended together without transition lines, use even pressure and trowel at a low angle using a sweeping motion.
- D. To remove squeegee lines and help the material level, immediately Loop Roll the material after it has been placed. The material should be rolled straight forward and back picking up the roller with each pass; this will avoid leaving divots in floor. After the squeegee lines have been removed the floor should be cross rolled side to side along the entire wet edge. The final cross roll should be completed within 12 minutes of mixing the product at 70°F.
- E. Wear spiked shoes and broadcast chips up into the air and let it fall onto the floor. Make sure the broadcast is dispersed evenly over the entire floor area at a rate of 0.1lbs per square foot using macro chip and 0.15 lbs per square foot using micro chip. Do not roll or walk back into areas that have been broadcast. Allow POLY-CRETE MD SL to cure for a minimum of 6 hours @ 70°F. At 70°F, broadcasting should not begin until 15 minutes after

the time the Poly-Crete SL was mixed. This time varies depending on temperature. Broadcasting needs to be completed within 30 minutes of mixing.

- F. Use a stiff bristle broom to sweep off excess chips. Use a vacuum to remove chips around the edges and corners that are not accessible with a broom.
- G. Scrape the floor with a trowel or floor scraper. Sweep and vacuum the floor again.

SECOND BROADCAST

- A. Measure out 1 part DUR-A-GLAZE #4 Regular or FAST hardener, and 2 parts DUR-A-GLAZE #4 Resin. First add the hardener into a separate mixing pail and then add the resin. Scrape the bottom and sides with a mix stick to ensure that all material is transferred to the mix bucket. Use the measuring pail to scrape the mix stick, and never scrape the mix stick on the side of the mix pail.
- B. Using a ½" 450 RPM drill with a Jiffler blade, mix the resin and hardener for 2 minutes.***DO NOT ADD RESIN TO HARDENER UNTIL BATCH IS READY FOR MIXING***
- C. Pour a 4" to 6" ribbon along the starting area. Use a 3" chip brush to cut in along edges, doorways, and drains.
- D. Using a 12" flat soft rubber window squeegee pull the material from side to side overlapping passes every 6". Be careful not to leave any puddles. DUR-A-GLAZE #4 is applied at 150 Sq. Ft per gallon over the decorative chips.
- E. Wear spiked shoes and back roll the material against the squeegee lines with a high quality 3/8" nap roller.
- F. Cross roll the material side to side overlapping the previous pass with half the roller width.
- G. Broadcast chips up into the air and let them fall onto the floor. Make sure the broadcast is dispersed evenly over the entire floor area at a rate of 0.1lbs per square foot using macro chip and 0.15 lbs per square foot using micro chip. Do not roll or walk back into areas that have been broadcast. Allow DUR-A-GLAZE #4 to cure for 4 hours @ 70°F.
- H. Use a vacuum to remove excess chips.
- I. Scrape the floor with a trowel or floor scraper. Sweep and vacuum the floor again.

GROUT COAT INSTRUCTIONS

- A. Measure out 1 part DUR-A-GLAZE #4 REGULAR hardener, and 2 parts DUR-A-GLAZE #4 Resin. First add the hardener to a separate mixing pail and then add the resin. Scrape bottom and sides with a mix stick to assure that all material is transferred to the mix bucket. Use the measuring pail to scrape the mix stick, and never scrape the mix stick on the side of the mix pail.
- B. Using a ½" 450 RPM drill with a Jiffler blade, mix the resin and hardener for 2 minutes.***DO NOT ADD RESIN TO HARDENER UNTIL BATCH IS READY FOR MIXING***
- C. Pour a 4 to 6" ribbon along the starting area. Use a 3" chip brush to cut in along edges, doorways, and drains.

- D. Using a 12" flat soft rubber window squeegee, pull the material from side to side overlapping passes every 6". Be careful not to leave any puddles. DUR-A-GLAZE #4 is applied at 150 Sq. Ft. per gallon over the decorative chips.
- E. Wear spiked shoes and back roll the material against the squeegee lines with a high quality 3/8" nap roller.
- F. Cross roll the material side to side overlapping the previous pass with half the roller width. Allow Product to cure for 10 hours @70°F.

- necessary to even out roller lines. Make sure to complete this roll within 10 minutes of the coating being placed.
- C. To prevent settling of the grit/powder, occasionally remix ARMOR TOP in a tray or bucket with a stick. Dry time is dependent on humidity as well as temperature.
- D. If recoating over 24 hours, sand floor using at least a 60 grit screen, solvent wipe and apply DUR-A-GLAZE #4 epoxy with SUPER STICK ADDITIVE at recommended rate. Re-apply ARMOR TOP next day.

TOP COAT INSTRUCTIONS

ARMOR TOP TOPCOAT

SPREAD RATES

Gloss Clear (w/grit)	= 575 SF/kit
Gloss Clear (no grit)	= 550 SF/kit
Gloss Pigmented (w/grit)	= 700 SF/kit
Gloss Pigmented (no grit)	= 675 SF/kit

Satin Clear (w/grit)	= 775 SF/kit
Satin Clear (no grit)	= 750 SF/kit
Satin Pigmented (w/grit)	= 850 SF/kit
Satin Pigmented (no grit)	= 825 SF/kit

NOTE: Armor Top is sold in kits only. Spread rates vary due to differences in gloss and satin kit sizes.

- A. Pour 1 gallon of ARMOR TOP hardener into a 2 gallon bucket. Add 1 Quart of ARMOR TOP Colorant and mix for 30 seconds. Add 1 Quart of ARMOR TOP resin and mix for 30 seconds. If additional abrasion resistance is required, slowly add 1 pint of ARMOR TOP Grit and continue mixing for an additional minute. Pour a small amount into a dip and roll tray that is large enough to accommodate an 18 inch roller.
- B. Dip roller cover into paint tray and roll off excess. Apply two 8-10 foot long paths from left to right then right to left. Re-wet roller and continue application. Even out roller lines by using W shaped crosses and/or up & down passes. If not even, re-roll up and down until uniform. A final cross-roll is

NOTE: This product is best suited for application in temperatures between 60°F and 85°F. Full chemical and abrasion resistance occurs in 7 days at 70°F. These properties will be attained more slowly at lower temperatures. Protect floor from chemical exposure and abrasive wear during this time.

IMPORTANT!

Before using DUR-A-FLEX products, read and understand its accompanying Safety Data Sheet.

STANDARD TERMS AND CONDITIONS OF SALE, INCLUDING STANDARD WARRANTY APPLY - VISIT DUR-A-FLEX.COM FOR THE LATEST VERSION

CAUTION! As with all chemical products, individuals may have different reactions to exposure to specific products. This is dependent upon many factors, including the individual's personal characteristics, the size of the installation, the ventilation available, the intensity of the exposure or the length of the exposure. Individuals may experience discomfort during the installation process of one product, but not another.

In some cases this is experienced as a skin irritation and in others it is experienced as an inhalant irritation. Typically, it disappears once the exposure is eliminated. In some cases people can become "sensitized" to a product and experience the discomfort every time there is exposure without Personal Protective Equipment ("PPE").

To protect yourself from various exposures or discomfort during the mixing and application of our products, we recommend covering exposed skin including, using gloves, long sleeves, safety glasses and a respirator such as the 3M 8577 P95 Universal Disposable Carbon Respirator or a cartridge respirator.

Use only as directed. KEEP OUT OF REACH OF CHILDREN.

Do not reseal moisture-contaminated hardener. This will result in carbon dioxide generation or possible violent rupture of container.